

POCKETFINDER VEHICLE INSTALLATION WARNINGS

LBT RECOMMENDS THAT CUSTOMERS USE A PROFESSIONAL AUTOMOTIVE TECHNICIAN TO INSTALL THEIR POCKETFINDER VEHICLE DEVICES.

LBT RECOMMENDS THAT CUSTOMERS INSTALL THEIR POCKETFINDER VEHICLE UNITS IN THE TRUNK OF THEIR VEHICLE OR UNDER THE DASHBOARD TO ENSURE MAXIMUM SAFETY. DO NOT INSTALL ANY POCKETFINDER DEVICE IN YOUR ENGINE COMPARTMENT.

ADDITIONAL PRECAUTIONS:

- 1) Engine must be turned off and cool prior to installing the device.
- 2) Do not place wires anywhere they may overheat.
- 3) Do not place wires anywhere that may cause them to be cut.

Last Updated 2/23/2012